

AUTOPILOT STANDARD OPERATING PRACTICES

- Always keep your heading bug synced with your actual or assigned heading. This keeps you engaged, ready for vectors, and helps you recognize a compass failure.
- Monitor vertical speed. If you are IFR and less than 500 FPM, report to ATC.
- Shallow the climb/descent rate prior to leveling off.
- Disengage autopilot and re-trim the flight controls after level off.
- TRIGGERS:
 - **“Fly heading xxx”** = Sync heading bug, engage HDG mode.
 - **“Intercept the final/localizer”** = ARM lateral mode only. No vertical mode.
 - **“Cleared for the approach”** = ARM approach (NAV, ILS, APPR, etc.)
- Say mode changes aloud and read them from the mode annunciator. Scan the dance card – mode annunciator – often.
- Using Vert Speed mode during climb or descent: STAY ENGAGED! You have no autopilot airspeed protection.
- When disconnecting the autopilot, hold the flight controls tightly in position. Do not hold them with a wet noodle hand.