

# iPad/ForeFlight Preflight Checklist

- FOREFLIGHT APP UP TO DATE**  
*Check the App Store to verify you have the latest version of ForeFlight installed.*
- FOREFLIGHT OPENS & FUNCTIONS NORMALLY**  
*Open and run ForeFlight to make sure the app is functioning normally.*
- CHARTS & DATABASES DOWNLOADED AND CURRENT**  
*Check the Downloads section of ForeFlight to verify all required charts are downloaded and current.*
- ROUTES, AIRPORTS, AND BINDERS LOADED**  
*Set favorite airports, routes and chart binders as required for the flight.*
- IPAD BATTERY CHARGED**  
*Ensure the iPad battery has enough charge to meet the requirements of the flight.*
- GPS OR ADS-B RECEIVER BATTERY CHARGED**  
*Ensure adequate charge on your wireless receiver's battery.*
- BACKUP POWER OR CHARGING CABLES AVAILABLE**  
*If required, ensure that a backup battery or charging cable is within reach.*
- STORAGE/MOUNTING DEVICES AVAILABLE**  
*Attach and secure required mounting devices (e.g. kneeboards, yoke mounts, etc.)*
- CONFIGURE WIRELESS RADIOS**  
*Set Airplane Mode, Bluetooth, Wi-Fi and Cellular Data to ON/OFF as required.*
- SET IPAD SCREEN BRIGHTNESS**  
*Clean the iPad screen and dim the screen brightness to conserve battery.*
- CLOSE ALL APPS NOT BEING USED**  
*Consider restarting the iPad and restarting ForeFlight to get a fresh, clean start.*