

Keyboard shortcuts

Garmin GNS430/530W

Desktop simulator

<u>Keyboard</u>	<u>Garmin</u>
Left Arrow	Little knob left
Right Arrow	Little knob right
Up Arrow	Big knob left
Down Arrow	Big knob right
Enter	Ent
Esc	Clr
D	Direct
M	Menu
P	Procedure
F	Flight Plan